# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9 SECRET

		8689-68 Copy 8 of 19	25X1A
		3 January 1968	
	MEMORANDUM FOR DISTRIBUTION		
	SUBJECT: DD/S&T Career Development Course		
25X1A	l. The OSA portion of the Career Devel will start on Wednesday, 28 February 1968. probably be held in the	opment Course Sessions will	
25X1A	2. The projected schedule is given in Please advise or changes.	Attachment I. of any errors	•
	3. Each presenting officer is requeste a course outline in the general format of At Such course outline should be submitted to on or before Friday, 18 January 1968.	d to prepare tachment II.	25X1A
,	4. The class enrollment is furnished in for your information.	n Attachment III	
			25X1A
	Assistant for Deputy Research and Special Ac	for Development	
	Attachments:		

OXCART/IDEALIST SECRET

I - Schedule

II - General Format III - Enrollment

HANDLE VIA 25X1A CONTROL SYSTEM

# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9 SECRET

		18689-68 Page 2
25X1A	A(T)D/R&D/OSA/(3 Jan 68) Distribution: Copy 1 - A(T)D/R&D/OSA 2 - D/SA 3 - EXO/SA	
	4 - COMPT/OSA 5 - D/R&D/OSA	
25X1A	6 - ASD/R&D/OSA 7 - PSD/R&D/OSA	
25X1A	8 - ASD/R&D/OSA 9 - SSD/R&D/OSA	
25X1A	10 - SS/OSA 11 - D/O/OSA	
	12 - OXC/O/OSA 13 - OXC/O/OSA	
	14 - OXC/O/OSA ( 15 - IDEA/O/OSA	
25X1A	16 - COMMO/O/OSA	
25X1A	17 - D/M/OSA	•
25X1A	18 - [ 19 - RB/OSA	

SECRET

HANDLE VIA 25X1A CONTROL SYSTEM

25X1A

# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9 SECRET

Attachment I

25X1A

	OSA COURSE SCHEDULE, CDC #2		
WEDNESDA	Y, 28 FEBRUARY		
0900	INTRODUCTION	General Bacalis	
0945	OSA ORGANIZATION		25X1A
1045	BREAK		
1100	INTERFACE WITH OTHER OFFICES		25X1A
1200	LUNCH		
1330	GENERAL BRIEFING ON OXCART AND IDEALIST PROGRAMS	OPS	
1630	DISMISSAL		
THURSDAY	, 29 FEBRUARY		25X1A
0900	ESTABLISHMENT OF SYSTEMS REQUIREMENTS AND DEVELOPMENT OF NEW SYSTEMS		
1100	PROJECT SECURITY (CONTRACTOR AND OPERATIONS)		25X1A
1200	DISMISSAL		
FRIDAY,	MARCH		ı
0900	HISTORICAL REVIEW OF OSA AND PROJECTS		25X1A
1045	BREAK		
1100	R&D: ENGINE PERFORMANCE		25X1A
1200	LUNCH		
	•		÷
	SECRET	HANDLE VIA CONTROL SYSTEM	25X1A

Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9 SECRET At  $\underline{\text{tach}}$  ment I to 8689-68 25X1A Page 2 FRIDAY, 1 MARCH (Continued) 1330 ENGINE PERFORMANCE, CONT R&D: 25X1A 1430 BREAK 1445 R&D: VEHICLE PERFORMANCE, 25X1A STRUCTURES 1630 DISMISSAL MONDAY, 4 MARCH 0900 ENGINE/AIRCRAFT INTERFACE 25X1A 1015 BREAK FLIGHT CONTROLS AND NAVIGATION 1030 25X1A 1200 LUNCH 1330 LIFE SUPPORT SYSTEMS 25X1A 1630 DISMISSAL TUESDAY, 5 MARCH 0900 SENSOR SYSTEMS 25X1A 1200 LUNCH 1330 R&D: PROJECT MANAGEMENT 25X1A 1430 SYSTEMS TEST AND VALIDATION OPS 1530 DISMISSAL WEDNESDAY, 6 MARCH CONFIGURATION MANAGEMENT AND 0900 OPS CONTROL 1045 BREAK 1100 COMMUNICATIONS 25X1A 1200 LUNCH SECRET 25X1A HANDLE VIA Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9EM

Ar	pproved For Redease 2002/11/13 ciClA RDP75B00285	R000300020017-9 Attachment I to 8689-68 Page 3	25X1A
WEDNESD	AY, 6 MARCH (Continued)		
1330	INTRODUCTION TO OPERATIONS	OPS	
1430	DISMISSAL		
THURSDAY	7, 7 MARCH		
0900	OPERATIONS, IDEALIST	IDEALIST OPS	
1015	BREAK		
1030	OPERATIONS, OXCART	OXCART OPS	
1200	LUNCH		į
1330	MATERIEL, LOGISTICS, AVIONICS		25X1A
1630	DISMISSAL		
FRIDAY,	8 MARCH		
1330	EXAMINATION		25X1A
1430	DISCUSSION SESSION	Mr. Duckett Col. Shelton	25X1A 25X1A

1630

DISMISSAL

25X1A

# Approved For Remains 2002/11/53:0 CHA-RDP75B00285R000300020017-9

Attachment	II	to	
8689-	68		25X1A

## EXAMPLE

LESSON TITLE: APPLICATION OF ADP IN OPERATIONS

DIVISION : AUTOMATIC DATA PROCESSING DIVISION/OSA

25X1A INSTRUCTOR :

DATE/TIME/ : APRIL 4, 1967/1500-1600/

PLACE

# PART I - OVERVIEW

- 1. LESSON OBJECTIVE: The objective of this lesson is for each student to become familiar with the purpose and scope of the data processing efforts in pre-mission, mission, and post-mission operations.
- 2. INSTRUCTIONAL AIDS: Charts, Slides
- 3. TIME REQUIRED: 60 Minutes
- 4. PLAN OF PRESENTATION: The instructor will introduce the lesson by a brief history of the ADP Division, its purpose, organizational structure, equipment, and interface with the Office of Computer Services. Three major areas will be discussed: flight planning, vulnerability studies, and 1004 communication net. The accomplishments to date will be discussed by describing the programs generated in support of OXCART and IDEALIST operations. The UNIVAC 1004 data communications network will be discussed giving specific reference to the equipment and its principles of operation. Miscellaneous activities in support of operations will be outlined so as to present a full picture of automation usage in operations.

## PART II' - TEACHING GUIDE

#### A. INTRODUCTION

- 1. Division's Purpose and History
- 2. Organization Structure
- 3. Hardware and Software Systems

EXAMPLE		
SECRET	HANDLE VIA CONTROL SYSTEM	25X1A

25X1

# SECRET Approved For Retrase 2002/11/13 : CIA-RDP75B00285R000300020017-9

		Attachment II to  8689-68 Page 2
	EXAMPLE	
	B. FLIGHT PLANNING	
	1. OXCART	
25X1A	(a) (b) (c) Mission Planning Aids	
25X1A	2. IDEALIST Project	
	C. VULNERABILITY STUDIES	
25X1A	Program	
25X1A	2. IDEALIST Project	
	D. UNIVAC 1004 DATA COMMUNICATIONS NETWORK	
	<ol> <li>Equipment Description</li> <li>Principles of Operation</li> <li>Remote Site Locations</li> </ol>	
	E. MISCELLANEOUS ACTIVITIES	
	<ol> <li>Operation Plan Generation</li> <li>Info Retrieval</li> <li>Map Plotting</li> <li>INS Readout</li> <li>Camera Programs</li> <li>Report Generation</li> </ol>	
25X1D	7.	

EXAMPLE

SECRET

HANDLE VIA \_\_\_\_\_ 25X1A CONTROL SYSTEM

25X1A

# Approved For Release 2002/11/13 COA-RDP75B00285R000300020017-9

Attachment II t	o 25X1A
Page 3	

# EXAMPLE

# List of Training Aids

# Briefing Boards

- 1. Type A and B turn for A-12
- 2. Flight Conditions
- 3. UNIVAC 1004 Data Link Equipment

Slide

UNIVAC 1004 Equipment

EXAMPLE

SECRET

HANDLE VIA \_\_\_\_\_ 25X1A CONTROL SYSTEM

# Approved For Release 2002/11/43 CFIA RDP75B00285R009300020017-9

Attachment II to	25X1A
Page 4	

## EXAMPLE

### Test Questions

- 1. List five benefits derived by the use of computers in flight planning.
- 2. List three reasons why a non-engineering model was chosen for the programming of the A-12 program.
- 3. List five major areas of concern in the Project program.

25X1A

- 4. Briefly describe the pitfalls of a vulnerability model.
- 5. List five major benefits of the UNIVAC 1004 as a communication terminal unit.

## **EXAMPLE**

SECRET

HANDLE VIA \_\_\_\_\_ 25X1A CONTROL SYSTEM

Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

**ILLEGIB** 

			S. 1-	41 ( 1 No. 18 11 11 11 11 11 11 11 11 11 11 11 11		
	Approved F	AT PAIANCE	2002/44/47	・ メー・メー ロフロ	フストロハハクタストハ	<u> </u>
*** * * *	YAPRIJUKEU I	OI LEIGHTE	2002/11/13	. CIA-NDI	13D00Z03R0	0
: -1 ()	4N(1 ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( )	-				

THANDLE WIN LONGROUND SYSTEM

2242-67 **25X1A** 

# Office of Special Activities

The Financial and Technical Management of System Development

# SCEEDULE

		Monday - 3 April	25X1A
0900	6F25	Welcoming Remarks	General Bacalis D/SA
0915	6F25	Intent, Scope and Content of Course	
0945	6F25	CSA Current Organization	
1030	6F25	Historical Development of the OSA Organization	
1230		LUNCH	1
1330	2E62	The Intelligence Collection Superstructure	AD/DCI/NIPE 25X1A 25X1A
1530	2E62	Working Relations with other offices	
1630		CLOSE	
		Tuesday - 4 April	
0900	6B12	The establishment and revision of system requirements.	25X1A SA/DD/S&T (COMOR)
1000	6B12	Project Briefing	25X1A
1200		LUNCH	25/1/
1300	6B12	Project Briefing	
1500	6B12	Application of ADP in Operations	
1600			25X1A rised 27 March 67
	$\neg$		NDLE VIA L

Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

		For Release 2002/11/13 : CFARDP75B00285R000390020	0017-9
	E VIA L OL SYS:	TEM	Page 3
OSA S	chedulo	e, Continued	
		Friday - 7 April	25X1A
0900	1E78	Air Force Systems Management Program	on film)
1200		LUNCH	25X1A
1300	6F25	Review and Examination	(with represent- atives of all offices involved
1600		CLOSE	to date)
		Monday - 10 April	25X1A
0900	6F25	Materiel and Logistics	Q5V4A
1200	Ø120	LUNCH	25X1A
1300	GA-13	OSA Security in Program Development	
1430	GA-13	Communications in Development and Operations	
1600		CLOSE	25X1A
		Tuesday - 11 April	25X1A
0900	GA-13	Aircraft Performance Analysis	
1030	GA-13	Engine Performance and Development	
1200		LUNCH	
1300	GA-13	The Aircraft-Engine Interface	
1345	GA-13	Flight Controls, Navigation, and Auxiliary Systems	
1515	GA-13	Sensor Development and User	

CLOSE

25X1A

Revised 27 March 67

HANDLE VIA

SECRET

CONTROL SYSTEM

1700

Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9 25X1A Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

SAMPLE PRESENTATION

FOR AMS/OSA


# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

# AERO MEDICAL STAFF (AMS) OFFICE OF SPECIAL ACTIVITIES

# I. MISSION STATEMENT

AMS/OSA is responsible to the Director, Special Activities for the aeromedical aspects of OSA, DDS&T operations, training, and research and development. The function of AMS is to insure that the operational aircrew member is properly evaluated and selected; that his health, both physical and mental, is maintained at peak effectiveness; and that his personal protective, survival, escape, and evasion equipment, and training are up-to-date and satisfactory in order that the aircrew member can participate effectively in attaining OSA mission objectives.

# II. STAFF RESPONSIBILITIES



# SECRET

Next 3 Page(s) In Document Exempt

#### SECRET

# Responsibility of Medical

# 1. Selection of Project Pilots

- a. Because of singular mission, every effort is made to select best from every aspect. Physical requirements, motivation, dedication, maturity, emotional stability, intelligence, adaptability, coordination, ability to get along with others, handle alcohol, etc.
- b. They receive astronaut's Physical Evaluation at School of Aviation Medicine (SAM), Brooks AFB, Texas.
- c. They are given a psychiatric interview by the Office of Medical Services' (OMS) psychiatrist and two to two-and-half day assessment and evaluation by psychologists from the Psychological Services Staff, OMS.

AMS/OSA, the Surgeon General's Office, a USAF-clear	ed 25X1A
liaison flight surgeon, and the Squadron Flight Sur	geon.

Aeromedical evaluation is made by the Chief,

- f. It must be realized that the original \_\_\_\_\_\_ 25X1A candidates nominated are top-flight, highest quality, and highly qualified jet pilots.
- g. The pilots are carefully monitored at all times by the Squadron Flight Surgeon and annually receive astronaut's examination at Lovelace Clinic, New Mexico.
- 2. All integrees receive a CIA physical initially. All key personnel also receive psychiatric interviews and psychological assessments. It has been noted that a key administrative officer can compromise a program as easily as a pilot.
- 3. Health and physical standards are maintained with all non-flying personnel receiving 18-month standby physical.

SECRET

# EXAMPLES OF INCREASED SAFETY AND RELIABILITY IN THE S1010 PPA

- 1. Normal/Emergency 02 delivery to the pilot.
- 2. Pressure protection in the event of cabin pressure loss or ejection.
- 3. Thermal protection on bailout, water survival, and cold-climate survival.
- 4. Integrated parachute harness.
- 5. Dual O<sub>2</sub> regulator, controller, and hose as well as dual O<sub>2</sub> storage.
- 6. Integrated flotation garment.
- 7. Fire protection for crash landing and/or cockpit fires.
- 8. Head and body protection from impact, dragging, or buffeting in flight and after ejection.
- 9. Installation of automatically activated life preserver.
- 10. Incorporation of 6-line release modification to personnel parachute.

## Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

SECRET		
	IDEA-0007-2-73 Copyof	25X1
	23 February 1973	

LESSON TITLE

: Aero Medical Programs

DIVISION

Aero Medical Staff/OSA

**INSTRUCTORS** 

DATE TIME PLACE

3 April 1973/1330-1600 - Control Center

Building 25X1A

25X1A

#### PART II - OVERVIEW

- LESSON OBJECTIVE: The objective of this lesson is for each student to become familiar with programs of the Aero Medical Staff/OSA. Specifically, the student will become familiar with the general physiological requirements for life-support equipment, the life-support system developed for and used in Project IDEALIST, and the Survival, Evasion, Resistance, and Escape (SERE) Training Program for project pilots.
- INSTRUCTIONAL AIDS: Vu-Graph Slides and overhead projector, 35 mm Slides and Projector, and 16 mm Movie and Projector.

TIME REQUIRED: 2 hours 30 minutes 25X1 CLASSIFIED BY EXEMPT FROM GEHERAL DECLASSIFICATION SCHEBULE OF E. O. 11652, EXEMPTION CATEGOEX § 50(1), (2), (3) or (4) (circle one or more) AUTOMATICALLY DECLASSIFIED ON SECRET IMPDET Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

4. PLAN OF PRESENTATION: The instructor will introduce the lesson by describing the overall organization and function of the Aero Medical Staff. Life-Support Programs will be discussed in Detail by describing the physiological requirements for life-support equipment, i. e., total barometric pressures, altered partial pressures, thermal balance, and protection during emergency ejections. In order to correlate physiological requirements with equipment in use, the life-support system as used in the U-2R will be discussed in detail. Finally, an overview of the

25X1

Training Program and related specialized equipment will be presented:

# PART II - TEACHING GUIDE

#### A. INTRODUCTION

- 1. Aero Medical Staff:
  - a. Organization and Function
  - b. Aircrew Selection
  - c. Maintenance
  - d. Resistance to Interrogation (RTI)

SECRET

25X1

IDEA-0007-2-73
Page 3

2. Life-Support Program Overview:

Equipment types and categories

- a. Aircraft Systems
- b. Aircrew Systems
- c. Training
- B. Physiological Requirements for Life-Support Equipment
  - 1. Total Barometric Pressure
    - a. Mechanical Effects of Pressure Change
      - (1) Areas affected
      - (2) Prevention/Protection
  - 2. Altered Partial Pressures
    - a. Decompression sickness
      - (1) Areas affected
      - (2) Protection/Prevention
    - b. Boiling of Body Fluids
      - (1) Areas affected
      - (2) Protection
    - c. Hypoxia
      - (1) Cause and Effects
      - (2) Protection
  - 3. Thermal Balance
    - a. Protection

SECRET

25X1

IDEA-0007-2-73
Page 4

25X1

- a. Protection (cont'd)
  - (1) From heat
  - (2) From cold
- 4. Escape Provisions
  - a. Hazards
    - (1) Decision
    - (2) Decompression
    - (3) Separation
    - (4) Windblast
    - (5) Deceleration
    - (6) Spin
    - (7) Hypoxia
    - (8) Frostbite
    - (9) Parachute Opening Shock
    - (10) Parachute Landing and Canopy Release
    - (11) Survival
- C. DESCRIPTION OF U-2R LIFE-SUPPORT EQUIPMENT
  - 1. Oxygen System
  - 2. Emergency Oxygen System
  - 3. Ejection System
  - 4. Pilot's Protective Assembly (PPA)
  - 5. Improvements

SECRET

# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9 CONTENTS

- I. A Review of High Altitude Physiology
  - A. Man and Oxygen
    - 1. The Normal Oxygen Environment
      - a. Atmospheric Oxygen
      - b. Oxygen in Man's Lungs at Sea Level
      - c. Oxygen in Man's Lungs at 10,000 Feet
    - 2. The Oxygen Environment Above 10,000 Feet
      - a. Breathing Air
      - b. Breathing Supplemental Oxygen
      - c. Using a Pressure Suit
      - d. A Word on Cabin Pressurization
  - B. Man and Nitrogen
    - 1. Nitrogen in the Body
    - 2. Decompression Sickness Cause
    - 3. Decompression Sickness Effects
      - a. Skin Manifestations
      - b. Bends
      - c. Chokes
      - d. Circulatory and Neurological Manifestations
    - 4. Decompression Sickness Treatment
    - 5. Decompression Sickness Prevention
      - a. Tissue Half-Times
      - b. Critical PN<sub>2</sub> for Various Altitudes and Pre-Breathing Requirements

# I. A REVIEW OF HIGH ALTITUDE PHYSIOLOGY

## A. Man and Oxygen

The fact that man requires a sufficient quantity of oxygen in order to metabolize nutrients and therefore produce energy is well known by all pilots of high performance/high altitude aircraft. After all, they have had one form of oxygen equipment or another strapped to their face, surrounding their head or entire body, while winking, blinking, and wheezing at them, almost since the first day they strapped a military aircraft on and penetrated the wild blue yonder. The following discussion will simply review the exact requirement for oxygen and the advantages of various types of oxygen delivery systems.

## 1. The Normal Oxygen Environment

## a. Atmospheric Oxygen

Since men (at least the majority) have lived on earth they have been exposed to near sea level environmental conditions and are therefore physiologically adapted to such conditions. The sea level environment has a normal barometric pressure of 760 mmHg and a normal atmospheric composition of 20.99% Oxygen, 78.03% Nitrogen, with water vapor and other gases making up the remaining fraction (See Table 1). While pressure decreases with increasing altitude above sea level, the percent composition of the atmosphere remains constant (with respect to all gases except water vapor) to an altitude of at least 60 miles. At sea level, man is exposed to an oxygen environment which exerts a pressure of 160 mmHg (also called the partial pressure of oxygen and abbreviated as PO2).

#### b. OXYGEN In Man's Lungs at Sea Level

The composition of air in man's lungs differs from the composition of the external environment for various reasons. Man's body contains a high percentage of water and his body temperature is constant, hence the water vapor pressure in his lungs will be constant at 47 mmHg. Normal ventilation of a healthy man's lungs is geared to maintain a constant Carbon Dioxide (CO<sub>2</sub>)

#### Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

Table 12. Effect of the Use of the Adjustable Press-to-Test Button on the prossure altitude within the S-1010 PPA

:Aircraft :Altitude	:Barometr : Pressur		:Cabin (2) (1):Altitude	: Pressur : manuall			
: (feet) :	: (psi) :	:Pressu: : (psi)	re : (feet) :	1.0 psi	2.0 psi	3.0 psi	: 3.47 psi
50,000	: : 1.69	: : 5.5°	: 7 : 24,500	: : 20,500	: : : : : : : : : : : : : : : : : : :	14,250	: : 13,000
55,000	: : 1.33	: : 5.2	: L : 26,000	: : 22,000	: 18,500:	15,250	: : 14,000
60,000	: : 1.05	4.93	: 3 : 27,500	: : 23,000	: 19,500:	1.6,000	: : 14,750
65,000	: : 0.83	4.7	: : 23,500	: : 24,000	: 20,250:	16,750	: : 15,500
70,000	: : 0.65	: : 4.53	: 3 : 29,000	: : 24,750	: 20,750:	17,500	: : 15,750
: :75,000	: : 0.51	: 4.39	30,000 30,000	: : 25,250	21,500:	18,000	: : 16,250
80,000	0.41	4.29	30,500	: : 25,750	21,750:	18,250	: : 16,750
: 100,000	0.16	: 4.04	31,500	: : 26,750	22,500:	19,000	: 17,500

<sup>(1)</sup> Constant  $\triangle P = 3.88$  psi (2) Closest 500 feet

## Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

pressure within his body throughout a wide range of physical activity (from complete rest to maximum physical exertion). This normal PCO<sub>2</sub> is 40 mmHg. Table 2 presents the composition and partial pressure of gases within man's lungs at sea level.

# c. Oxygen in Man's Lungs at 10,000 Feet

All pilots also know that a normal, healthy man can function well at 10,000 feet above sea level as long as the physical activity is limited. That is, he can fly his aircraft at 10,000 feet without supplemental oxygen, but above 10,000 feet he must utilize some form of oxygen equipment. Hence the oxygen pressure at 10,000 feet represents the minimum tolerable level and the oxygen pressure at sea level represents the optimum level. Therefore, oxygen pressures between these two values (ie 60 to 100 mmHg) can be considered normal for a pilot engaged in flying his aircraft. The values for 10,000 feet are given in Table 3.

# 2. The Oxygen Environment Above 10,000 Feet

# a. Breathing Air

As barometric pressure is reduced with increasing altitude, so is the oxygen pressure within man's lungs. His body will attempt to compensate for this reduction by increasing ventilation to blow off CO2 and thus make more "room" for oxygen. However, the effectiveness of this compensation is minimal since lowered  ${
m CO}_2$  causes constriction of the blood vessels supplying the brain, therefore adding to the effect of oxygen deficiency on the central nervous system. At oxygen pressures less than 60 mmHg, the degree of impairment to a pilot is generally expressed in terms of Time of Useful Consciousness (T.U.C.). The T.U.C. for a given altitude (or PO2) represents the average exposure time before a pilot engaged in minimal physical activity is no longer able to perform effectively (ie make correct decisions, control his aircraft, etc.). T.U.C. for a given individual can vary markedly from day to day depending on many factors. Table 4 presents the oxygen and T.U.C. situation for various altitudes above 10,000 feet.

# b. Breathing Supplemental Oxygen

The basis for using some type of oxygen equipment for flight above 10,000 feet is that the reduction in barometric pressure can be offset by increasing the percentage of oxygen in the inspired air. The goal is to maintain a PO2 in the lungs which is close to that found at sea level. It is obvious that once an altitude is reached where 100% oxygen is required to maintain a normal PO2 in the lungs, additional efforts are required to ascend beyond this Pressure breathing (ie supplying 100% oxygen to the mask/lungs under a pressure over and above ambient pressure) extends mans altitude ceiling slightly, but has definite limitations. Two adverse effects which limit the effectiveness of pressure breathing are: (1) the possibility of lung damage, and (2) impairment of circulation. Lung damage can be produced if oxygen is supplied to the lungs at pressures greater than about 50 mmHg above ambient (ie above the pressure on the rest of the body). Impairment of blood circulation occurs, with increasing severity, as the pressure in the lungs is increased to any degree above ambient. Table 5 presents the PO2 and T.U.C. situation for various altitudes above 10,000 feet for a pilot using ordinary diluter demand oxygen equipment. Table 6 presents the situation for pressure breathing above 40,000 feet.

#### c. Using a Pressure Suit

The only method by which sufficient oxygen pressure can be safely applied to man's lungs to allow him to fly at altitudes in excess of 45,000 feet, is to apply an equal counterpressure to the outside of his body. One method is to apply equal counterpressure only to the torso of the body, but this does not eliminate the problem of circulatory impairment and therefore only raises man's altitude ceiling slightly. A pressure suit therefore is a device which applies a pressure over the entire body that is equal to the oxygen pressure being applied to the lungs. This can be done by applying a mechanical pressure ("squeezing" action) over the body's surface as is done in,

#### Approved For Release 2002/11/13: CIA-RDP75B00285R890300020017-9

what have come to be called, "partial pressure suits." Various methods of squeezing the body for counterpressure have been developed over the years, but the most widely accepted and used garment is the U.S. Air Force developed "Capstan/Torso. Bladder" partial pressure suit. The torso bladder is inflated to the same pressure as delivered to the oxygen inflated helmet, and is connected to the helmet so that slight changes in pressure during the breathing cycle are compensated for automatically. capstans are elongated bladders which, when inflated, are one fifth the diameter of the individuals limbs and which apply equal counterpressure by tightening the inelastic material of the pressure suit over the extremities. Capstans over the torso region tighten the suit material to prevent the torso bladder from ballooning excessively, and therefore aid in mobility of the pilot. A full pressure suit is a pneumatic pressure suit that can be visualized as a man-shaped, form-fitting pressurized cabin. When inflated to balance the required oxygen pressure in the lungs, the full pressure suit expands away from, rather than squeezing, the body. Because the oxygen pressure delivered to the lungs is balanced by gas pressure instead of mechanical pressure, comfort in the inflated full pressure suit is greatly improved over the partial pressure suit. compares the protection provided by the two types of pressure suits, revealing that the full pressure suit provides the pilot with a 35,000 ft equivalent altitude and the partial pressure suit provides a 40,000 ft equivalent altitude. One other feature of all pressure suits is that 100% oxygen is breathed at all altitudes. While this provides a higher  $\overline{\text{PO}_2}$ than required at altitudes under 35,000 feet, it provides for elimination of Nitrogen from the body which will be discussed in a later section.

# d. A Word on Cabin Pressurization

The previous discussions of the effects of breathing air or supplemental oxygen, and the use of pressure breathing or pressure suits at various altitudes assumed that the pilot was exposed to the same ambient altitude at which

Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9 these conditions represent an emergency condition or at least an abnormal state since all modern aircraft utilize cabin pressurization as the primary system for providing physiological protection. In some aircraft, which can tolerate a large pressure differential and therefore maintain a low cabin altitude, oxygen equipment is used only as a backup or emergency system in the event of loss of cabin pressure. other types of aircraft, cabin pressure and supplemental oxygen are used in combination to provide protection. In the aircraft of concern here the later case exists. Under normal operating conditions the pressure suit is merely providing supplemental oxygen (100% as previously noted) at cabin altitudes which exceed 10,000 feet and may reach 30,000 feet. With failure of the pressurization system to maintain at least 35,000 feet cabin altitude, the S-1010 PPA will take over the complete role of providing protection. Figure 1

presents the cabin pressurization schedule which

will be used in combination with the S-1010

Pilots Protective Assembly.

# Approved For Release 2002/11/13: CIA-RDP75B00285R999300020017-9 B. Man and Nitrogen

While free gaseous nitrogen is said to be physiologically inert, it can have serious indirect effects when man is exposed to changing barometric pressures. The disorder related to nitrogen is called <u>Decompression Sickness</u>, which includes a wide variety of symptoms that may occur during or following a decompression (ie during or following a change from a high to a low pressure environment).

- Nitrogen in the Body. Gaseous nitrogen is very l. soluble in man's body (about 5 times more soluble in fat than in water) and, as long as he remains at sea level, the quantities and tension (pressure) of nitrogen in his body remain constant. absolute quantity of dissolved nitrogen depends on the size of the individual and the amount of fat in his The tension of dissolved nitrogen at sea level body. for all men breathing air will be identical since the dissolved tension will equal the PN2 in the lungs. Therefore the nitrogen tension in the body of a man who has been residing at sea level for a finite period of time is 573 mmHg (See Table 2). The dissolved nitrogen in the body can be eliminated or reduced in either of two ways: (1) by reducing the level of or by eliminating Nitrogen in the gas mixture being breathed, or (2) by breathing air at a reduced total pressure, ie, at altitudes above sea level. In the first case either 100% oxygen, a mixture with less than 78% nitrogen, or a mixture containing normal oxygen but with the nitrogen replaced by another inert gas (Helium, Argon, Neon, etc.) will accomplish the reduction or elimination of nitrogen. In considering the flying business only, the only practical approach to reducing or eliminating Nitrogen from the body is the breathing of 100% oxygen before ascent to altitude. This approach will be discussed in detail in a later paragraph.
- 2. Decompression Sickness Cause. While the disorder called decompression sickness (or caisson disease, bends, compressed air illness, evolved gas dysbarism) has been recognized for over 100 years, the exact physiological mechanisms giving rise to the various forms of the disorder are still not definitely known. However, the basic cause of all forms of decompression sickness is attributed to the formation of gaseous bubbles in the body during or following reduction of barometric pressure on the body. The chief gas involved in bubble formation is Nitrogen. Nitrogen bubbles can

- Approved For Release 2002/11/13: CIA-RDP75B00285Ree0300020017-9
  Dody Whenever the dissolved nitrogen tension (PN2) exceeds the total barometric pressure (PB) on the body by a critical amount: While the exact value for the critical difference is not known (it may differ between individuals, or may differ depending on absolute values of PN2 and PB) the range of values which can give rise to altitude decompression sickness is pretty well pinned down. The critical value is actually expressed as a ratio of Dissolved PN2 to total PB (PN2/PB). The highest value tolerable without the formation of bubbles is felt to be a ratio of 2/1, and the lower limit for a ratio which may give rise to bubbles is probably 1.5/1. In summary then, decompression sickness can occur whenever bubbles of Nitrogen are formed in the body during or following reduction of ambient pressure. Further, nitrogen bubbles can be formed whenever the dissolved Nitrogen tension in the body exceeds the total barometric pressure on the body by a factor of 1.5 to 2.0.
- 3. Decompression Sickness -- Effects. The signs and symptoms of this disorder are generally classified into 4 or 5 groups as follows:
  - a. Skin Manifestations. Isolated areas of the skin may itch or give rise to a hot, burning sensation. An affected area may display a mottled, raised or blotchy appearance. While these symptoms are minor in themselves, they are sometimes seen in conjunction (preceeding or simultaneously) with more serious symptoms.
  - b. Bends. The most common symptoms of decompression sickness are pains in or near one or more of the body joints. The pain is generally deep and aching, becomes progressively more severe, is aggrevated by exercise of the affected area, and may become incapacitating.
  - c. Chokes. This serious form of decompression sickness has substermal burning, restricted breathing (due to pain), and a hacking cough as symptoms. In very serious cases, cyanosis (blueing of lips, fingernails) may appear. While these symptoms are generally seen in conjunction with others (bends, skin rashes etc), the chokes may occasionally be the only symptom experienced.

- Approved For Release 2002/11/11 NGIA FDP75B00285R 3096200179s. The most serious forms of decompression sickness involve either the circulatory system, the nervous system or both simultaneously. Symptoms may range from visual disturbances and headache through paralysis, delirium, shock, coma, and death.
- Decompression Sickness Treatment. For the pilot who encounters any form of decompression sickness in flight there is only one course of action -- to increase the pressure on his body to reduce or eliminate the This can be accomplished by descent, altering bubbles. cabin pressure (if possible), or altering pressure within his pressure suit (if a suit is being worn). For the serious symptoms it is obvious that immediate descent to ground level is required. As an adjunct to the primary treatment (ie recompression) the pilot should remain on 100% oxygen all the way to ground level. Finally, even if symptoms are relieved in flight or upon return to ground level, the incident should be immediately made known to the flight surgeon because of the distinct possibility of a delayed reoccurrence or reaction.
- Decompression Sickness Prevention. In a previous paragraph it was stated that Nitrogen could be reduced or eliminated from the body by breathing 100% oxygen prior to ascent to altitude -- a procedure called "Prebreathing" or "Denitrogenation." The rationale for this procedure is to reduce the dissolved Nitrogen tension to a level where the critical ratio of PN2/ PB=1.5 to 2.0 won't be encountered at the maximum altitude to which the pilot may be subsequently exposed. When a pilot breathes 100% oxygen at sea level, the nitrogen pressure (PN2) in his lungs rapidly drops to zero. The blood flowing through the lungs contains a PN2 of 573 mmHg and thus a pressure gradient of 573 to 0 exists and Nitrogen leaves the blood to be exhaled. This Nitrogen-free blood then passes through the body tissues and reabsorbs Nitrogen (tissue PN, is still 573 mmHg at this point) and again loses if on the next circuit through the lungs. As this process continues the pressure gradient from the blood to the lungs and from the tissues to the blood is decreasing exponentially, thus the rate of Nitrogen elimination drops off with The rate of Nitrogen elimination is also affected by two other factors: (1) different areas of the body contain different absolute quantities of Nitrogen dictated by the different amount of fat they contain, and (2) different areas of the body have different rates of blood flow, dictated by metabolic activity of the tissues involved. These two factors in combination

#### Approved For Release 2002/11/13: CIA-RDP75B00285R060300020017-9

are most critical with regards to Nitrogen elimination and the potential for decompression sickness, since the critical ratio of PN<sub>2</sub>/P<sub>B</sub>, which relates to bubble formation, exists for each of the many types of tissues in the body. Therefore, while almost all Nitrogen can be eliminated in a short time from areas of the body with little fat and/or high rates of blood flow, areas with high fat content and/or low blood flows may retain a high PN<sub>2</sub> even after long periods of prebreathing. For determining nitrogen elimination the body is considered to have areas giving rise to 6 or more different nitrogen elimination rates, generally expressed as "half-times."

- A tissue half-time is the Tissue Half-Times. time, in minutes, required for a tissue to lose one-half of its excess nitrogen content when exposed to a given gradient. Since bubble formation is dependent on Nitrogen pressure, the half-time of a tissue can also be expressed with respect to the PN2 of a tissue. For purposes of determining prebreathing requirements the body is considered to have the following half-time tissues: 20, 40, 80, and 120 minutes. Table 8 displays the relationship between half-times, percent desaturation and PN2. From this table it can be seen that only the slowest equilibrating tissue needs to be considered in the prevention of bubble formation by the process of denitrogenation. Hence the following prebreathing requirements are based on reducing the PN2 of the 120 minute half-time tissue to a safe level with respect to the PN2/PB ratio.
- b. Critical PNo for Various Altitudes and Pre-Breathing Requirements. By using the PNo/PB ratio and the PB for various altitudes, the critical PNo for the 120 minute (or any other) half-time tissue can be calculated. Then the prebreathing time required to reduce the PNo to or below this critical value can be obtained from the nitrogen elimination curve (or equation) for the 120 minute tissue. Table 9 presents the critical PNos and Figures 2a, 2b, and Table 10 present the prebreathing requirements for these altitudes.

#### Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

TABLE 1

COMPOSITION OF THE ATMOSPHERE (DRY)

						•		
GASES :	N <sub>2</sub>	02	ARGON	CO <sub>2</sub>	II <sub>2</sub>	Ne	Не	Others
VOL % :	78.03	20.99	0.94	0.03	0.01	0.0012	0.0004	Traces
SEA LEVEL PARTIAL PRESSURE:		160 maily	7 mi	nHg (us	ually i	ncluded w	ith PN2)	

	······································		<del></del>		
0	TABLE 2				
NORMAL COMPOSITION OF A	IR WITHIN MAN'S	LUNGS	AT	SEA	LEVEL
, ·	PRESSURE			vc	DL %
BAROMETRIC PRESSURE:  OXYGEN (PO <sub>2</sub> ):  NITROGEN (PN <sub>2</sub> ):  CARBON DIOXIDE(PCO <sub>2</sub> ):  WATER VAPOR (PI <sub>2</sub> O):	760 mmHg 100 mmHg 573 mmHg 40 mmHG 47 mmHg			1	00% 3.2% 5.3% 5.3% 6.2%

TABLE 3
NORMAL PRESSURES OF RESPIRATORY GASES IN MAN'S LUNGS AT 10,000 FEET ABOVE SEA LEVEL
BAROMETRIC PRESSURE: 523 mmHg PO2 : 61 mmHg PN2 : 380 mmHg PCO2 : 35 mmHg* PH <sub>2</sub> O : 47 ten fix

<sup>\*</sup>The reduction in  $PO_2$  stimulates normal ventilation, thus reducing the  $PCO_2$  slightly.

# Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

TABLE 4

EFFECT OF INCREASING ALTITUDE ON MAN BREATHING AMBIENT AIR

EFFECT OF	INCREASING ALT	TIODE (	DIA BIETTA	DREATH	M.C. HWDIL	INI AIR
ALTITUDE	BAROMETRIC				mmHg)	
(Ft above S.L.)	PRESSURE	PH <sub>2</sub> O	PCO2	$PN_2$	PO <sub>2</sub>	T.U.C.
			·			
10,000	523 mmHg	47	35	380	61	Indefinite
18,000	380 mmHg	47	30	265	38	30 min
20,000	350 mmHg	47	30	239	34	10-15 min
25,000	282 mmHg	47	27	178	30	3-5 min
30,000	226 mmHg	47	27*	128	24	60-90 sec
35,000	180 mmHg	47	27*	87	19	30-60 sec
40,000	141 mmHg	47	27*	52	15	15-20 sec
50,000	87 mmHg	47	27*	4	9	9-12 sec
. 63,000	47 mmHg	47	0	0	0	9-12 sec

<sup>\*</sup>Assumes PCO<sub>2</sub> does not fall below 27 mmHg. Measured values are unavailable at altitudes above 25,000 feet because the onset of hypoxia is so rapid.

Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

TABLE 5

EFFECT OF SUPPLEMENTAL OXYGEN ON MAN AT ALTITUDES FROM 10,000 TO 63,000 FEET

ALTITUDE (Feet above S.L.		BAROMETRIC PRESSURE	PERCENT OXYGEN	RESPIR	ATORY GA	SES (mmHg)	EQUIVALENT · ALTITUDE	T.U.C.
1100		(mmHg)	INSPIRED	$PH_2O$	$PCO_2$	$PO_2$	*	
	10,000	523	31	47	40	100	S.L.	Indefinite
	13,000	380	42	47	40	100	S.L.	Indefinite
	20,000	350	46 ·	47	40	100	S.L.	Indefinite
	25,000	282	57	47	40	100	S.L.	Indefinite
	30,000	226	71	47	40	100	S.L.	Indefinite
•	35,000	180	100	47	40	93	S.L.	Indefinita
	40,000	141	100	47	35	59	10,000	Indefinite
	45,000	111	100	47	30	34	20,000	10-15 min
	50,000	87	100	47	27	13	40,000	15 sec
2)	63,000	47	100	47	0	0	63,000	9-12 sec

<sup>\*</sup>Altitude breathing air that yields same PO2.

#### Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

TABLE 6
EFFECTS OF PRESSURE BREATHING ON MANS TOLERANCE TO HIGH ALTITUDES

ALTITUDE (Ft above S.L.)	BAROMETRIC PRESSURE	PERCENT INSPIRED OXYGEN	ADDITIONAL PRESSURE(1) REQUIRED	ADDITIONAL PRESSURE(2) DELIVERED	GASES PCO <sub>2</sub>	(mmHg)	EQUIV ALT	T.U.C. (3)
35,000	180 .	100	0	3-5 mmHg*	40	100	S.L.	Indef
40,000	141	100	0-40	5-8 mmHg	35	64-67	10,000	Ind
43,000	122	100	20-60	14 mmHg	35	54	12,000	Indef
45,000	111	100	30-70	20 mmHg	35	49	15,000	30 min
50,000	87	100	54-93	· 30 mmHg	30	34	20,000	3 min
63,000	47	100	94-133	30 mmHg	27	3	63,000	9-12 se


<sup>(1)</sup> Additional pressure required; range of pressures that would produce a PO<sub>2</sub> equivalent to that obtained breathing air at 10,000 feet to sea level.

<sup>(2)</sup> Additional pressure delivered: are actual pressure values delivered by standard pressure demand regulators. Are less than required because of adverse effects of higher pressures.

<sup>(3)</sup> T.U.C.: actual values may be less than shown due to circulatory impairment caused by pressure breathing having an additive effect to low PO<sub>2</sub>.

<sup>\*</sup>Slight pressure delivered at 35,000 is "safety pressure", used to overcome mask leakage.

### Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9



Pique 2a  175  Pique 2a  Nitragen Elimmation Curve For 120 minute  200  Half Time Tissue with Evitaal PN2s  for various Afficuated Tindicated.  Data From Tabble 9 indicated by  Altstude in feet and PN2/PB Billio  (in parentheses) PN2 573 minute  218  (50)  Time 2 O and 10070 Onysen Breathed  200  For Indicated Time.  225  235  235  235  235  235  235  23		Approved For	Release 2002/11/13 : CIA-RDP75B00285Rec030002	0017-9
175   Figure 2a	(25%)			
Vi Tragen Elimon Flor Curve For 120 minute				
Half Time Tissue with Critical PN28  for Various Afficuacy Endicated  Data From Tabble 9 Indicated by  Altstude in fect and PN2/PB Ratio  (in parentheses). PNa 573 mmHz at  (in parentheses). PNa 573 mmHz at  (soi). Time 20 and 100% Oxygen Breathed  300	175		Figureau	
Half Time Tissue with Critical PN28  for Various Aftitudes Indicated  Data From Tabble 9 indicated by  Litstude in feet and PN2/PB Ratio  (in parentheses). PNa 573 mmHz att			Vitrogon Floring tion Curve For 1201	omute
125   100   1250   100   1250   100   1250   100   1250   100	200		Unit Time Locke with Critical	N2'S
Data From Tabble 9 indicate d by  250 Altstude in fect and Pha/PB Ratio  (in parentheses). Pha 573 minute at  (soc) Times 0 and 100% Oxygen Breathed  200 For Indicated Time.  325 35,000 (2.0)  315 425 425 425 425 550 475 550 475 550 456 456 456 456 456 457,500 (2.0)	205		for Various Attitudes Indicated	
Altitude in Fect and PNa/PB Ration (in parentheses)   PNa 573 mmth at			Dato From Table 9- indicate d	by
(in parentheses). PN = 573 mnHz at (50%). Time & O and (00%) Oxygen Byeat hed (50%). Time & O and (00%) Oxygen Byeat hed (50%). Time & O and (50%) Oxygen Byeat hed (50%). Time & O and (5	250		Altatude in East and PNA/PB 1	atio
100   100			1 1 573 mm	Haat
30b for Indicate a Time.  325 358 358 3000 (2.0) 315 425 425 425 500 47,500 (2.0) 570 25,000 (2.6)	275		The 3 of and 100% Oxygen Bre	thea
325 35000 (35) 350 350 350 350 3500 (35) 350 350 350 350 350 350 350 350 350 350	700		그 그 보다 그 나는 사람들이 되는 사람들이 되었다. 그리고 그리고 나타를 하는 하는 모든 말하다 말라.	
35, oco (2.0) 375 400 425 425 425 425 425 426 427,500 (2.0) 526 527,500 (2.0)	300			
350 (2.0) 375 400 425 425 425 425 425 425 425 425 425 425	325		┩╬╌╬╌╬╌╬╌╬╌╬╌╬╌╬┸╬╌╬┸╬╌╬┸╬╌╬┸╬╌╬┸╬╌╬┸╬╌╬	
315 400 425 425 425 425 560 47,800 (3.0) 570 25,000 (3.0)				30,000(15
425 425 425 475 500 27,800 (2.6) 535 550 25,000 (2.6)	3.50			35,000 (2.0)
425 425 475 475 500 27,800 (2.6) 570 25,000 (2.6) 30,000 (2.6)	275			500 (1.5)
425 425 425 425 425 425 426 427,800 (2.6) 525 525 525 525 525 525 525 52				
425 475 500 27,800 (2.6) 525 530 25,000 (2.0)	400			
550 535 27,800 (2.0)			25,000 (1)	5)
560 27,800 (2.0) 535 23,000 (2.0)	425			
560 27,800 (2.0) 535 23,000 (2.0)	A.T.73-		20,000 (2.6)	
500 27,800 (2.0) 525 25,000 (2.0)	130			
500 27,800 (2.0) 535 23,000 (2.0)	475			
535				
535			27,800 (2.0)	
570 23,006 (2.0)				<u> - </u>
570 23,000 (2.0)				
570	550			
	570		- 23,000-(2.0)	
			30 Ap 50 60 70 10	90-100-110 1

150								: : · · · · · · · · · · · · · · · · · ·		
		-								
175		-1		1191	re o	( D		-   -   -   - <sub> </sub> -   -   -   -   -   -	<u> </u>	
			(Co	tenual	ion c	FF	gur-e		ر. د د د سیستریس	
200	,				ol (a)-				100	000'(
aar					- - - - - -			-  <sub> -</sub>  .	40,	700
250										
					35,00	0	<b>2</b> \			
27	5		+	10.6	00' (2	- ~				
				10,0	00.6					
30	0									
30.	5									
300						++++			++++	
35										
37	5				- -;- -;-  - -;- - - -					
40	0									
42										
	<b>2</b>			- - <del> </del> - - - -						9.
45	0									
A'7	5						-   -   -	-   -   -   -		
1										
50									-	
52	5				- - - -					
	1 . 1 : ! 1 1 1						- <del> - - - </del> - - - - - - - - - - - - - - -			
-55	0			- <del>  -   -   -   -   -   -   -   -   -  </del>	- - - - - -					
-99										
<del></del>	Ap <b>le S</b> ved H		0 130 ase 2002/1	1/13 CIA- Time	-1					00

# Approved For Release 2002/11/13 : CIA-RDP75B00285R000300020017-9

TABLE 7

Physiological Protection Provided by the Standard Capstan/Torso Bladder-type Partial Pressure Suit.

Pressure St ALTITUDE Ft above S.L.	BAROMETRIC PRESSURE (nualig) (PSI)	BLADDER/ HELMET , PRESSURE	PO2 (mmHg)	EQUI√. OXYGEN ALTITUDE (1)	CAPSTAN , PRESSURE (PSI)	BODY PRESSURE (PSI)	EQUIVALENT PRESSURE ALTITUDE (2)
40,000	141 2.73	(mmHg)  4  55  100  145	63	10,000	0	2.73	40,000
50,000	87 1.69		60	10,000	5	2.69	40,000
63,000	47 .91		65	10,000	10	2.91	38,500
100,000	8 .16		60	10,000	14.5	2.95	38,500

- (1) Equivalent oxygen altitude: altitude breathing air that yields same  $PO_2$ .
- Equivalent pressure altitude: Pressure altitude obtained by total of suit pressure plus ambient pressure.
- Physiological Protection Provided by a Full Pressure Suit (3.5 PSI type).

•	BAROMETRIC PRESSURE numlig PSI	SUIT PRESSURE (gage) mmHg PSI	PO <sub>2</sub> mmIIg	EQUIV. OXYGEN ALTITUDE (1)	ABSOLUTE PRESSURE IN SUIT	EQUIVALENT PRESSURE ALTITUDE (2)
35,000 40,000 50,000 63,000 100,000	179 3.47 141 2.73 87 1.69 47 0.91 8 0.16	$egin{array}{cccccccccccccccccccccccccccccccccccc$	100 100	S.L. S.L. S.L. S.L. S.L.	3.47 3.47 3.47 3.47 3.47	35,000 35,000 35,000 35,000 35,000

# Approved For Release 2002/11/13: CIA-RDP75B00285R000300020017-9

#### TABLE S

The relationship between Percent Nitrogen Desaturation,  $PN_2$  and Time for Tissue Half-Times from 5 to 120 minutes. All tissues assumed to have 570 mmHg  $PN_2$  (100% saturation) at T=0, and maximum gradient applied at T=0 (ie 100% oxygen breathed).

Time (T) in Minutes to Attain Given  $PN_2$  and % Desaturation

) :	570	285	142.5	71.25	35.6	17.8	8.9
Desaturation (%):		50	75	87.5	93.75	96.9	98.4
5	0	5	. 10	15	20	25	30
10	0	10	20	30	40	50	60
20	0	20	40	60	80	100	120
40	0	40	80	120 -	160	200	240
80	0	80	160	240	320	400	480
120	0	120	240	360	480	600	720
	5 10 20 40 80	5 0 10 0 20 0 40 0 80 0	5     0     5       10     0     10       20     0     20       40     0     40       80     0     80	5     0     5     .10       10     0     10     20       20     0     20     40       40     0     40     80       80     0     80     160	ion (%):     0     50     75     87.5       5     0     5     . 10     15       10     0     10     20     30       20     0     20     40     60       40     0     40     80     120       80     0     80     160     240	ion (%):     0     50     75     87.5     93.75       5     0     5     10     15     20       10     0     10     20     30     40       20     0     20     40     60     80       40     0     40     80     120     160       80     0     80     160     240     320	Lon (%):     0     50     75     87.5     93.75     96.9       5     0     5     .10     15     20     25       10     0     10     20     30     40     50       20     0     20     40     60     80     100       40     0     40     80     120     160     200       80     0     80     160     240     320     400

TABLE 9 Critical Tissue  $PN_2$  for Various Exposure Altitudes and Critical  $PN_2/P_B$  Ratios of 2.0 and 1.5.

Exposure Altitude	Barometric Pressure	Critical Tissue PN2 at Indicated Ratio		
(Feet above S.L.)	(mmHg)	2.0	1.5	
25,000	282	564 mmHg	<b>423</b> mmHg	
27,500	253	506	379.5	
30,000	226	452	339	
35,000	179	358	268.5	
40,000	141	282	211.5	

TABLE 10

Prebreathing Time required to reduce  $PN_2$  of 120 minute tissue to critical level for various exposure altitudes, using  $PN_2/PB = 2.0$  and 1.5 ratios from Figures 2a and 2b.

Altitude (Feet above S.L.)	Time Breathing 100% Oxygen at S.L. To Reduce $PN_2$ to Critical Valve For $PN_2/P_B$ Indicated		
	$PN_2/P_B = 2.0$	$PN_2/P_B = 1.5$	
25,000	3 min	53 min	
27,500	21 min	<b>7</b> 1 min	
30,000	41 min	90 min	
35,000	80 min	131 min	
40,000	123 min	171 min	

Table 11.

Suit Pressure	:	Exposure altitude :
Applied		requiring this
(psi)	:	Pressure (feet)
	:	;
0.5	:	38,000
1.0	:	42,000
	:	
1.5	:	47,000
2.0	:	53,000
2.5	:	62,000
3.0	:	77,000
3.47	:	Space